

# PACKING RISERS IN THE NEW SECONDARY RISERS COVERS IN THE EV02



---

EV02 / PACKING IMSTRUCTIONS / RISERS / SECONDARY RISERS COVERS

---

REV 1  
DATE 11.24 . 25



EMAIL: [USA@FLYFIREBIRD.COM](mailto:USA@FLYFIREBIRD.COM) / [WWW.FLYFIREBIRD.COM](http://WWW.FLYFIREBIRD.COM)  
409 N MAIN ST. ELOY, AZ. 85131  
1405 FLIGHTLINE BLVD, DELAND FL 32724 USA  
PHONE: +1.747.300.8880

## **HOW TO PACK THE RISERS IN THE NEW SECONDARY RISER COVERS ON YOUR EV02 - PAGE 1**

**FOLLOW THE STEPS BELOW TO CORRECTLY ROUTE, POSITION, AND SECURE THE RISERS WITH THE NEW SECONDARY RISER COVERS ON THE EV02 SYSTEM. PROPER PACKING ENSURES CLEAN RISER PRESENTATION, RELIABLE DEPLOYMENT, AND OPTIMAL AESTHETICS.**



**1. PLACE THE RISERS ON TOP OF EACH OTHER, ROUTING THEM UNDERNEATH THE MAIN RISER COVER**

**2. CONTINUE ROUTING UNTIL YOU REACH THE SECONDARY RISER COVER.**



**3. SPLIT THE RISERS SO THEY RUN PARALLEL TO ONE OTHER.**

**4. POSITION THE REAR RISER AT THE BOTTOM OF THE SIDEWALL, ENSURING THE TOGGLE FACES THE RESERVE TRAY.**

**5. MAKE SURE THE REAR RISER LIES COMPLETELY FLAT BEFORE PROCEEDING.**



**6. PLACE THE FRONT RISER PARALLEL TO THE REAR RISER, UNDERNEATH THE SECONDARY RISER COVER, WITH THE DIVE LOOPS FACING THE RESERVE TRAY. ENSURE IT IS AS FLAT AS POSSIBLE.**



**7. CLOSE THE SECONDARY RISER COVER, MAKING SURE IT IS FULLY STRETCHED & COMPLETELY COVERING BOTH THE FRONT & REAR RISERS.**

**THE BINDING TAPE OF THE SECONDARY RISER COVER SHOULD BE POSITIONED AS CLOSE AS POSSIBLE TO THE BOTTOM OF THE CONTAINER THE BACKPACK.**



**8. CLOSING THE MAIN RISER COVERS: HOLD THE SECONDARY RISER COVER IN PLACE WITH THE SIDEWALL, THEN PROCEED TO CLOSE THE MAIN RISER COVER. INSERT THE POINTY TIP FIRST.**

**ENSURE THE MAGNETS ALIGN PROPERLY, AND CONFIRM THAT THE SECONDARY RISER COVER REMAINS FULLY STRETCHED TO MAINTAIN OPTIMAL AESTHETICS AND PROPER MEMORY IN YOUR EV02.**



**9. VERIFY RISER ALIGNMENT AND RISER RAMP ROUTING:**

**MAKE SURE THE RISERS RUN PARALLEL ALL THE WAY TO THE RISER RAMPS,**

**ENSURE THE SOFT LINKS AND CANOPY LINES FOLLOW THE RISER RAMPS TO PREVENT ANY CANOPY LINES FROM GETTING ROUTED TO THE BOTTOM OF THE RESERVE TRAY.**

**10. REPEAT THE ENTIRE PROCESS ON THE OPPOSITE SIDE TO COMPLETE THE SECONDARY AND MAIN RISER COVER PACKING SETUP.**

**11. PLACE THE MAIN DEPLOYMENT BAG INTO THE MAIN TRAY AND PROCEED TO CLOSE THE CONTAINER, COMPLETING THE PACK JOB.**

**12. VERIFY THE SECONDARY RISER COVER ALIGNMENT.**

**AFTER CLOSING THE MAIN TRAY, CHECK THAT THE SECONDARY RISER COVERS ARE STILL CORRECTLY POSITIONED TO ENSURE PROPER COVERAGE AND MAINTAIN CLEAN AESTHETICS.**

**🔥 IF YOU HAVE ANY QUESTIONS, PLEASE FEEL FREE TO CONTACT FIREBIRD. OUR MASTER RIGGER WILL BE HAPPY TO ASSIST YOU WITH ANYTHING YOU NEED.**

**[WWW.FLYFIREBIRD.COM/FB/CONTACT-FB](http://WWW.FLYFIREBIRD.COM/FB/CONTACT-FB)**

**FIREBIRD**

